

## DC14 Infrared Magnetizing&Deactivated &Detect Machine Manual



### Spec:

Name:	Infrared Magnetizing&Deactivated &Detect Machine
Model No.:	EC-DC14
Brand:	EANT
The scope of application:	Libraries, bookstores, pharmacies, cosmetic stores
Dimensions:	33.6cm*22.2cm*9cm
Magnetizing power:	≤95W
Deactivate power:	≤95W
Detecting power:	≤10W
Operating voltage AC:	AC: 220V ± 10%, 50Hz
Magnetizing effective height:	≤50mm
Deactivate effective height:	≤50mm
Detecting height:	≤20mm
Alarm Mode:	Sound and lights flash
G.W:	8.4kg/Unit

### Instructions::

1, The machine is three function in one machine, it is divided into two parts, each can work independently. Arrow Center as the boundary, left arrow area is detecting region, right arrow area is Magnetizing& Deactivate region. Magnetic stripe detection region will keep working if power on, magnetic stripe Magnetizing& Deactivate region only will work when the transfer switch on the corresponding position. The region between two white lines on the glasses surface is effective working region, slide the product over the effective region when need magnetizing or Deactivate.

2, If only check the magnetic stripe, keep the transfer switch on the middle position, then power on. Slide the product that need to be detect inside the effective region as the arrow's direction, the product with magnetic stripe will let the machine alarm, if the machine didn't alarm means the magnetic stripe already had been Deactivated or had been damaged.

3, When the library needs to return the book or when the Shopping malls need to return the goods, turn the switch to Magnetizing position, Magnetizing Led on. Slid the book or goods which carry the magnetic stripe inside the effective working region, magnetic stripe will have sensitivity again. When slid to the detection region, the machine will alarm.

4, When the library need to lend the book out or the goods after paid, turn the switch to Deactivate position, Deactivate led on. Slid the book or goods which carry the magnetic stripe inside the effective working region, magnetic stripe will be Deactivated. When slid to the detection region, the machine will not alarm.

### Tip:

- 1, The machine should install more than two meters away from the EM antenna.
- 2, Product that fear of magnetization such as Magnetic stripe, mobile, watches should keep far from the machine who is working.
- 3, Please make sure that slid the item inside the effective region, otherwise may cause the magnetic stripe can not be full Magnetizing or Deactivate or didn't been detected.
- 4, When turn the swift to Magnetizing or Deactivate, sometimes will effect the detection region, make the machine alarm shortly, that is normal situation. This sound is totally different as the sound when detected the magnetic stripe, will not Confused.
- 5, Because this machine have large power, please make sure power off when you transfer the function, or make sure the function led off then turn the swift. Otherwise will damage this machine very easily.
6. Please read the instructions for use, damaged by the user misuse is not covered under the warranty